


Bolt User Guide



Battery Installation

1. Locate battery door on bottom of toy.
2. Open battery door and position 4 AA batteries as shown in diagram 1.
3. Close battery door.

Operating Instructions


Automatic Mode

- Press on/off button to turn on.
- Set on a safe, flat surface such as a table or floor.
- Bolt will automatically turn off after 15 minutes.
- Press on/off button to turn off before 15 minutes.

Manual Mode

- Press on/off button to turn on.
- Press on/off button and hold for 3 seconds.
- Hold in your hand and aim Bolt wherever you like to create your own laser patterns.
- Bolt will automatically turn off after 15 minutes.
- Press on/off button to turn off before 15 minutes.

In Automatic or Manual Mode, you can adjust the mirror to aim the laser across a variety of surfaces as shown in diagram 2.



⚠ WARNING

Do not aim the laser light directly into the eyes of pets or people.

Always supervise pets playing with pet toys. Monitor your pet's reaction to the laser light, and reward with tangible toy, treat or affection after play session. Pets should be supervised while playing with the toy. If you notice your pet exhibiting unusual behavior, immediately discontinue use of the toy and consult your veterinarian before using the toy again.

Apart from playing with the toy, pet owners should provide their pets with a variety of play activities, opportunities for stimulation, and an appropriate amount of daily exercise as determined by you and your veterinarian. Be involved in play sessions with your pets and be generous with your attention, hugs, and encouraging words.

This product is intended for pets, not for children. Do not allow small children to use this product to play with your pet without adult supervisions

To Ensure Proper Function

Do not mix old and new batteries.

Do not mix standard, alkaline, or rechargeable batteries.

Only use batteries of the same or equivalent type as recommended.

Exhausted batteries should be removed immediately.

Do not dispose of batteries with household waste.

Inspect this product periodically for damage and discard it immediately if it appears worn or broken.

